


# **HITACHI**

## **SERVICE MANUAL**

TK

No. 3509E

# **VM-C1E(RS)**



## *Technical Data*

This Technical Data manual shows only the schematic and circuit board diagrams, exploded views and parts lists of VM-C1E(RS). Since the disassembly and adjustment procedures (chapter 1 to 4) are the same as in the VM-C1E, refer to the VM-C1E Technical Data (No. 3244E) issue previously for these items.

### MANUAL RELATED TO THE VM-C1E(RS)


TITLE	MODEL	MANUAL No.
Technical Data	VM-C1E	No. 3244E
Technical Information	VM-C1E	No. 3245E
Technical Data	VM-AC80E/ VM-RF81E	No. 3327E, G



This video deck is a VHS-C type video recorder. For proper operation, only the VHS-C type cassette must be used.

### SAFETY PRECAUTIONS

The following precautions should be observed when servicing.

1. Since many parts in the unit have special safety-related characteristics, always use genuine Hitachi replacement parts. Especially critical parts in the power circuit block should not be replaced with other makers' parts! Critical parts are marked  in the schematic diagrams.
2. Before returning a repaired unit to the customer, the servicing technician must thoroughly test the unit to ascertain that it is completely safe to operate without danger of electrical shock.

SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT

## **VIDEO CASSETTE RECORDER**


June

1991

TOKAI WORKS


# CIRCUIT BOARD CONNECTION DIAGRAM CAMERA SECTION


# LEITERPLATTEN-ANSCHLUSSDIAGRAMM KAMERATEIL



## C











NOTE: MARK (Z) IS LEADLESS (CHIP) JUMPER

To  
PROCESS  
PG105

To  
PROCESS  
PG106

To POWER SUPPLY CN981

